



Tank Outlet Valves

PROVEN SOLUTIONS ENGINEERED FOR DEMANDING APPLICATIONS

- ANGLE STEM FLUSH TANK VALVES
- RADIAL DIAPHRAGM TANK VALVES
- RADIUS MOUNTED VALVES
- FLUSH TANK VALVES WITH CROWN FLATS
- SPRAY BALL VALVES
- SAMPLING VALVES





TANK BOTTOM VALVES

keep media flowing

IGENIX® RADIAL DIAPHRAGM TANK OUTLET VALVES


- Smooth sloping design for complete drainage
- 1/2" through 3", DIN 15 through DIN 80
- 45° outlet, clamp and weld connections available
- 316L weld pads are stocked for immediate shipment
- Machined by PBM from wrought material
- Standard finish 15 Ra with EP (BPE SF4)



RDV CONFIGURATIONS




Point of Use



Extended Weld Pad



Clamp On with Purge Port



Standard Weld Pad with Satellite Valve



Tangential









Custom fit Copper Chill Block fixtures are available to facilitate welding of PBM's Radial Diaphragm tank outlet valve weld pad.







www.PBMVALVE.com

PBM's Tank Bottom Valves:


- Eliminate dead leg at bottom of the tank
- Have unobstructed flow to empty the tank quickly
- Seals on the upstream seat to allow body cavity to drain or be purged and cleaned
- Standard flush pad design will fit most tank configurations



Clean, purge valve in closed position.



Steam or cleaning solution goes in purge port.



Solution then goes around body and down through flats.







INDUSTRIAL VALVES

FULL PORT

- Angle Stem Flush Tank
- Flush Tank
- Control Valves

SANITARY VALVES

BPE COMPLIANT

- Radial Diaphragm Valves
- Angle Stem Flush Tank
- Flush Tank Ball Valves
- Control Valves

SPECIALTY VALVES


- · Manifold Assemblies
- Crown Flat Face
- Spray Ball Valves
- Sampling Valves

AUTOMATION

- Electric & Pneumatic
- Direct Mount
- Torque outputs of 25,000 in-lbs.
- Bi-Directional Travel Adjustments
- Pneumatic and Electro-Pneumatic positioners


www.PBMVALVE.com

IMI PBM's standard flush tank pad incorporates a unique radius that facilitates flow to the valve and reduces dead space where media could stagnate. The pad is designed to weld flush with the inside tank surface for strategic positioning of the ball. PBM's standard flush tank pad will fit most tank configurations, such as dished, flat, ellipsoidal, jacketed, conical or spherical.



Cylindrical radius pads or reduced pocket cylindrical radius pads keep media flowing smoothly by minimizing dead space.






Spherical radius pads or reduced pocket spherical radius pads facilitate efficient drainage and reduces the pocket area above the ball.

Industrial Angle Stem Valve





www.PBMValve.com



PBM, Inc. • 1070 Sandy Hill Road, Irwin, PA 15642
Phone: 800.967.4PBM • 724.863.0550 • Fax: 724.864.9255
E-mail: info.pbmvalve@imi-critical.com

